




Degrease the place where you will fix the Skipper.



Using the marked stickers, check the correct distance from the door.




Mark the position of the Skipper with a pencil.



Check that the Skipper is correctly positioned by opening and closing the overhead door.



Using pliers, bend the cut-out lips to the shape of the door so that it seals properly.



Check the position of the Skipper again by raising and lowering the door and adjust if necessary.



Remove the marked stickers and permanently fix the Skipper to the wall.



Optional: Screw the Skipper to the wall using the screws provided. (correct drill size supplied)