




*Degrease the place where you will fix the Skipper.*




*Using the marked stickers, check the correct distance from the door.*




*Mark the position of the Skipper with a pencil.*




*Check that the Skipper is correctly positioned by opening and closing the overhead door.*




*Using pliers, bend the cut-out lips to the shape of the door so that it seals properly.*



*Check the position of the Skipper again by raising and lowering the door and adjust if necessary.*



*Remove the marked stickers and permanently fix the Skipper to the wall.*



*Optional: Screw the Skipper to the wall using the screws provided. (correct drill size supplied)*